

RTEMS Shell User's Guide

Edition 4.9.1, for RTEMS 4.9.1

28 February 2008

On-Line Applications Research Corporation

COPYRIGHT © 1988 - 2008.
On-Line Applications Research Corporation (OAR).

The authors have used their best efforts in preparing this material. These efforts include the development, research, and testing of the theories and programs to determine their effectiveness. No warranty of any kind, expressed or implied, with regard to the software or the material contained in this document is provided. No liability arising out of the application or use of any product described in this document is assumed. The authors reserve the right to revise this material and to make changes from time to time in the content hereof without obligation to notify anyone of such revision or changes.

The RTEMS Project is hosted at <http://www.rtems.com>. Any inquiries concerning RTEMS, its related support components, its documentation, or any custom services for RTEMS should be directed to the contacts listed on that site. A current list of RTEMS Support Providers is at <http://www.rtems.com/support.html>.

Table of Contents

Preface	1
1 Configuration and Initialization	3
1.1 Introduction	3
1.2 Configuration	3
1.2.1 Customizing the Command Set	3
1.2.2 Adding Custom Commands	3
1.3 Initialization	5
1.3.1 Attached to a Serial Port	5
1.3.2 Attached to a Socket	5
1.4 Functions	5
1.4.1 rtems_shell_init - initialize the shell	6
2 General Commands	7
2.1 Introduction	7
2.2 Commands	7
2.2.1 alias - add alias for an existing command	8
2.2.2 date - print or set current date and time	9
2.2.3 echo - produce message in a shell script	10
2.2.4 sleep - delay for a specified amount of time	12
2.2.5 id - show uid gid euid and egid	13
2.2.6 tty - show ttyname	14
2.2.7 whoami - print effective user id	15
2.2.8 logoff - logoff from the system	16
2.2.9 exit - exit the shell	17
3 File and Directory Commands	19
3.1 Introduction	19
3.2 Commands	19
3.2.1 umask - set file mode creation mask	20
3.2.2 cp - copy files	21
3.2.3 pwd - print work directory	25
3.2.4 ls - list files in the directory	26
3.2.5 chdir - change the current directory	28
3.2.6 mkdir - create a directory	29
3.2.7 rmdir - remove empty directories	31
3.2.8 chroot - change the root directory	32
3.2.9 chmod - change permissions of a file	33
3.2.10 cat - display file contents	35
3.2.11 rm - remove files	36
3.2.12 mount - mount disk	37
3.2.13 unmount - unmount disk	39

3.2.14	blksync - sync the block driver	40
3.2.15	dir - alias for ls	41
3.2.16	cd - alias for chdir	42
4	Memory Commands	43
4.1	Introduction	43
4.2	Commands	43
4.2.1	mdump - display contents of memory	44
4.2.2	wdump - display contents of memory (word)	45
4.2.3	medit - modify contents of memory	46
4.2.4	mfill - file memory with pattern	47
4.2.5	mmove - move contents of memory	49
4.2.6	malloc - obtain information on C program heap	50
5	RTEMS Specific Commands	53
5.1	Introduction	53
5.2	Commands	53
5.2.1	cpuuse - print or reset per thread cpu usage	54
5.2.2	stackuse - print per thread stack usage	56
5.2.3	perioduse - print or reset per period usage	57
5.2.4	wkspc - display information on executive workspace	59
5.2.5	config - show the system configuration	61
5.2.6	itask - list init tasks for the system	62
5.2.7	extension - display information about extensions	63
5.2.8	task - display information about tasks	64
5.2.9	queue - display information about message queues	65
5.2.10	sema - display information about semaphores	66
5.2.11	region - display information about regions	67
5.2.12	part - display information about partitions	68
5.2.13	object - display information about rtems objects	69
5.2.14	driver - display the rtems device driver table	70
5.2.15	dname - displays information about named drivers	71
5.2.16	pthread - display information about POSIX threads	72
6	Network Commands	73
6.1	Introduction	73
6.2	Commands	73
6.2.1	netstats - obtain network statistics	74
6.2.2	ifconfig - configure a network interface	77
6.2.3	route - show or manipulate the ip routing table	79
	Function and Variable Index	81
	Concept Index	83
	Command Index	85

Preface

Real-time embedded systems vary widely based upon their operational and maintenance requirements. Some of these systems provide ways for the user or developer to interact with them. This interaction could be used for operational, diagnostic, or configuration purposes. The capabilities described in this manual are those provided with RTEMS to provide a command line interface for user access. Some of these commands will be familiar as standard POSIX utilities while others are RTEMS specific or helpful in debugging and analyzing an embedded system. As a simple example of the powerful and very familiar capabilities that the RTEMS Shell provides to an application, consider the following example which hints at some of the capabilities available:

```
Welcome to rtems-4.8.99.0(SPARC/w/FPU/sis)
COPYRIGHT (c) 1989-2008.
On-Line Applications Research Corporation (OAR).

Login into RTEMS

login: rtems
Password:

RTEMS SHELL (Ver.1.0-FRC):/dev/console. Feb 28 2008. 'help' to list commands.
SHLL [/] $ cat /etc/passwd
root:*:0:0:root:::/bin/sh
rtems:*:1:1:RTEMS Application:::/bin/sh
tty!:2:2:tty owner:::/bin/false
SHLL [/] $ ls /dev
-rwxr-xr-x  1 rtems  root           0 Jan 01 00:00 console
-rwxr-xr-x  1 root   root           0 Jan 01 00:00 console_b
2 files 0 bytes occupied
SHLL [/] $ stackuse
Stack usage by thread
  ID      NAME      LOW      HIGH      CURRENT  AVAILABLE  USED
0x09010001 IDLE 0x023d89a0 - 0x023d99af 0x023d9760    4096    608
0x0a010001 UI1  0x023d9f30 - 0x023daf3f 0x023dad18    4096   1804
0x0a010002 SHLL 0x023db4c0 - 0x023df4cf 0x023de9d0   16384   6204
0xffffffff INTR 0x023d2760 - 0x023d375f 0x00000000    4080    316
SHLL [/] $ mount -L
File systems: msdos
SHLL [/] $
```

In the above example, the user *rtems* logs into a SPARC based RTEMS system. The first command is `cat /etc/passwd`. This simple command lets us know that this application is running the In Memory File System (IMFS) and that the infrastructure has provided dummy entries for `/etc/passwd` and a few other files. The contents of `/etc/passwd` let us know that the user could have logged in as `root`. In fact, the `root` user has more permissions than `rtems` who is not allowed to write into the filesystem.

The second command is `ls /dev` which lets us know that RTEMS has POSIX-style device nodes which can be accessed through standard I/O function calls.

The third command executed is the RTEMS specific `stackuse` which gives a report on the stack usage of each thread in the system. Since stack overflows are a common error in deeply embedded systems, this is a surprising simple, yet powerful debugging aid.

Finally, the last command, `mount -L` hints that RTEMS supports a variety of mountable filesystems. With support for MS-DOS FAT on IDE/ATA and Flash devices as well as network-based filesystems such as NFS and TFTP, the standard free RTEMS provides a robust infrastructure for embedded applications.

This manual describes the RTEMS Shell and its command set. In our terminology, the Shell is just a loop reading user input and turning that input into commands with argument. The Shell provided with RTEMS is a simple command reading loop with limited scripting capabilities. It can be connected to via a standard serial port or connected to the RTEMS `telnetd` server for use across a network.

Each command in the command set is implemented as a single subroutine which has a *main-style* prototype. The commands interpret their arguments and operate upon stdin, stdout, and stderr by default. This allows each command to be invoked independent of the shell.

The described separation of shell from commands from communications mechanism was an important design goal. At one level, the RTEMS Shell is a complete shell environment providing access to multiple POSIX compliant filesystems and TCP/IP stack. The subset of capabilities available is easy to configure and the standard Shell can be logged into from either a serial port or via telnet. But at another level, the Shell is a large set of components which can be integrated into the user's developed command interpreter. In either case, it is trivial to add custom commands to the command set available.

1 Configuration and Initialization

1.1 Introduction

This chapter provides information on how the application configures and initializes the RTEMS shell.

1.2 Configuration

The command set available to the application is user configurable. It is configured using a mechanism similar to the `confdefs.h` mechanism used to specify application configuration.

In the simplest case, if the user wishes to configure a command set with all commands available that are neither filesystem management (e.g. mounting, formatting, etc.) or network related, then the following is all that is required:

```
#define CONFIGURE_SHELL_COMMANDS_INIT
#define CONFIGURE_SHELL_COMMANDS_ALL

#include <rtems/shellconfig.h>
```

In a slightly more complex example, if the user wishes to include all networking commands as well as support for mounting MS-DOS and NFS filesystems, then the following is all that is required:

```
#define CONFIGURE_SHELL_COMMANDS_INIT
#define CONFIGURE_SHELL_COMMANDS_ALL
#define CONFIGURE_SHELL_MOUNT_MSDOS
#define CONFIGURE_SHELL_MOUNT_NFS

#include <rtems/shellconfig.h>
```

1.2.1 Customizing the Command Set

The user can configure specific command sets by either building up the set from individual commands or starting with a complete set and disabling individual commands. Each command has two configuration macros associated with it.

CONFIGURE_SHELL_COMMAND_XXX

Each command has a constant of this form which is defined when building a command set by individually enabling specific commands.

CONFIGURE_SHELL_NO_COMMAND_XXX

In contrast, each command has a similar command which is defined when the application is configuring a command set by disabling specific commands in the set.

1.2.2 Adding Custom Commands

One of the design goals of the RTEMS Shell was to make it easy for a user to add custom commands specific to their application. We believe this design goal was accomplished. In order to add a custom command, the user is required to do the following:

- Provide a *main-style* function which implements the command. If that command function uses a `getopt` related function to parse arguments, it **MUST** use the reentrant form.
- Provide a command definition structure of type `rtems_shell_cmd_t`.
- Configure that command using the `CONFIGURE_SHELL_USER_COMMANDS` macro.

Custom aliases are configured similarly but the user only provides an alias definition structure of type `rtems_shell_alias_t` and configures the alias via the `CONFIGURE_SHELL_USER_ALIASES` macro.

In the following example, we have implemented a custom command named `usercmd` which simply prints the arguments it was passed. We have also provided an alias for `usercmd` named `userecho`.

```
#include <rtems/shell.h>

int main_usercmd(int argc, char **argv)
{
    int i;
    printf( "UserCommand: argc=%d\n", argc );
    for (i=0 ; i<argc ; i++ )
        printf( "argv[%d]= %s\n", i, argv[i] );
    return 0;
}

rtems_shell_cmd_t Shell_USERCMD_Command = {
    "usercmd",           /* name */
    "usercmd n1 [n2 [n3...]]", /* usage */
    "user",             /* topic */
    main_usercmd,       /* command */
    NULL,               /* alias */
    NULL                /* next */
};

rtems_shell_alias_t Shell_USERECHO_Alias = {
    "usercmd",          /* command */
    "userecho"         /* alias */
};

#define CONFIGURE_SHELL_USER_COMMANDS &Shell_USERCMD_Command
#define CONFIGURE_SHELL_USER_ALIASES &Shell_USERECHO_Alias
#define CONFIGURE_SHELL_COMMANDS_INIT
#define CONFIGURE_SHELL_COMMANDS_ALL
#define CONFIGURE_SHELL_MOUNT_MSDOS

#include <rtems/shellconfig.h>
```

Notice in the above example, that the user wrote the *main* for their command (e.g. `main_usercmd`) which looks much like any other `main()`. They then defined a `rtems_shell_cmd_t` structure named `Shell_USERCMD_Command` which describes that command. This command definition structure is registered into the static command set by defining `CONFIGURE_SHELL_USER_COMMANDS` to `&Shell_USERCMD_Command`.

Similarly, to add the `userecho` alias, the user provides the alias definition structure named `Shell_USERECHO_Alias` and defines `CONFIGURE_SHELL_USER_ALIASES` to configure the alias.

The user can configure any number of commands and aliases in this manner.

1.3 Initialization

The shell may be easily attached to a serial port or to the `telnetd` server. This section describes how that is accomplished.

1.3.1 Attached to a Serial Port

Starting the shell attached to the console or a serial port is very simple. The user invokes `rtems_shell_init` with parameters to indicate the characteristics of the task that will be executing the shell including name, stack size, and priority. The user also specifies the device that the shell is to be attached to.

This example is taken from the `fileio` sample test. This shell portion of this test can be run on any target which provides a console with input and output capabilities. It does not include any commands which cannot be supported on all BSPs. The source code for this test is in `testsuites/samples/fileio` with the shell configuration in the `init.c` file.

```
#include <rtems/shell.h>

void start_shell(void)
{
    printf(" =====\n");
    printf(" starting shell\n");
    printf(" =====\n");
    rtems_shell_init(
        "SHLL",                /* task name */
        RTEMS_MINIMUM_STACK_SIZE * 4, /* task stack size */
        100,                  /* task priority */
        "/dev/console",       /* device name */
        0,                    /* run forever */
        1                      /* wait for shell to terminate */
    );
}
```

In the above example, the call to `rtems_shell_init` spawns a task to run the RTEMS Shell attached to `/dev/console` and executing at priority 100. The caller suspends itself and lets the shell take over the console device. When the shell is exited by the user, then control returns to the caller.

1.3.2 Attached to a Socket

TBD

1.4 Functions

This section describes the Shell related C functions which are publicly available related to initialization and configuration.

1.4.1 rtems_shell_init - initialize the shell

CALLING SEQUENCE:

```
rtems_status_code  rtems_shell_init (  
    char            *task_name,  
    uint32_t        task_stacksize,  
    rtems_task_priority  task_priority,  
    char            *devname,  
    tcflag_t        tcflag,  
    int             forever  
);
```

DIRECTIVE STATUS CODES:

RTEMS_SUCCESSFUL - Shell task spawned successfully
others - to indicate a failure condition

DESCRIPTION:

This service creates a task with the specified characteristics to run the RTEMS Shell attached to the specified `devname`.

NOTES:

This method invokes the `rtems_task_create` and `rtems_task_start` directives and as such may return any status code that those directives may return.

2 General Commands

2.1 Introduction

The RTEMS shell has the following general commands:

- `alias` - Add alias for an existing command
- `date` - Print or set current date and time
- `echo` - Produce message in a shell script
- `sleep` - Delay for a specified amount of time
- `id` - show uid gid euid and egid
- `tty` - show ttyname
- `whoami` - print effective user id
- `logoff` - logoff from the system
- `exit` - alias for logoff command

2.2 Commands

This section details the General Commands available. A subsection is dedicated to each of the commands and describes the behavior and configuration of that command as well as providing an example usage.

2.2.1 alias - add alias for an existing command

SYNOPSIS:

```
alias oldCommand newCommand
```

DESCRIPTION:

This command adds an alternate name for an existing command to the command set.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `alias`:

```
SHLL [/] $ me
shell:me command not found
SHLL [/] $ alias whoami me
SHLL [/] $ me
rtems
SHLL [/] $ whoami
rtems
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_ALIAS` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_ALIAS` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `alias` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_alias(
    int    argc,
    char **argv
);
```

The configuration structure for the `alias` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_ALIAS_Command;
```

2.2.2 date - print or set current date and time

SYNOPSIS:

```
date
date DATE TIME
```

DESCRIPTION:

This command operates one of two modes. When invoked with no arguments, it prints the current date and time. When invoked with both `date` and `time` arguments, it sets the current time.

The `date` is specified in YYYY-MM-DD format. The `time` is specified in HH:MM:SS format.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

This comm

EXAMPLES:

The following is an example of how to use `date`:

```
SHLL [/] $ date
Fri Jan 1 00:00:09 1988
SHLL [/] $ date 2008-02-29 06:45:32
SHLL [/] $ date
Fri Feb 29 06:45:35 2008
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_DATE` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_DATE` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `date` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_date(
    int    argc,
    char **argv
);
```

The configuration structure for the `date` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_DATE_Command;
```

2.2.3 echo - produce message in a shell script

SYNOPSIS:

```
echo [-n | -e] args ...
```

DESCRIPTION:

echo prints its arguments on the standard output, separated by spaces. Unless the **-n** option is present, a newline is output following the arguments. The **-e** option causes echo to treat the escape sequences specially, as described in the following paragraph. The **-e** option is the default, and is provided solely for compatibility with other systems. Only one of the options **-n** and **-e** may be given.

If any of the following sequences of characters is encountered during output, the sequence is not output. Instead, the specified action is performed:

\b	A backspace character is output.
\c	Subsequent output is suppressed. This is normally used at the end of the last argument to suppress the trailing newline that echo would otherwise output.
\f	Output a form feed.
\n	Output a newline character.
\r	Output a carriage return.
\t	Output a (horizontal) tab character.
\v	Output a vertical tab.
\0digits	Output the character whose value is given by zero to three digits. If there are zero digits, a nul character is output.
\\	Output a backslash.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

The octal character escape mechanism (**\0digits**) differs from the C language mechanism.

There is no way to force **echo** to treat its arguments literally, rather than interpreting them as options and escape sequences.

EXAMPLES:

The following is an example of how to use **echo**:

```
SHLL [/] $ echo a b c
a b c
SHLL [/] $ echo
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_ECHO` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_ECHO` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `echo` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_echo(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the `echo` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_ECHO_Command;
```

ORIGIN:

The implementation and portions of the documentation for this command are from NetBSD 4.0.

2.2.4 sleep - delay for a specified amount of time

SYNOPSIS:

```
sleep seconds
sleep seconds nanoseconds
```

DESCRIPTION:

This command causes the task executing the shell to block for the specified number of `seconds` and `nanoseconds`.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

This command is implemented using the `nanosleep()` method.

The command line interface is similar to the `sleep` command found on POSIX systems but the addition of the `nanoseconds` parameter allows fine grained delays in shell scripts without adding another command such as `usleep`.

EXAMPLES:

The following is an example of how to use `sleep`:

```
SHLL [/] $ sleep 10
SHLL [/] $ sleep 0 5000000
```

It is not clear from the above but there is a ten second pause after executing the first command before the prompt is printed. The second command completes very quickly from a human perspective and there is no noticeable delay in the prompt being printed.

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_SLEEP` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_SLEEP` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `sleep` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_sleep(
    int    argc,
    char **argv
);
```

The configuration structure for the `sleep` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_SLEEP_Command;
```


2.2.5 id - show uid gid euid and egid

SYNOPSIS:

```
id
```

DESCRIPTION:

This command prints the user identity. This includes the user id (uid), group id (gid), effective user id (euid), and effective group id (egid).

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

Remember there is only one POSIX process in a single processor RTEMS application. Each thread may have its own user identity and that identity is used by the filesystem to enforce permissions.

EXAMPLES:

The first example of the `id` command is from a session logged in as the normal user `rtems`:

```
SHLL [/] # id
uid=1(rtems),gid=1(rtems),euid=1(rtems),egid=1(rtems)
```

The second example of the `id` command is from a session logged in as the `root` user:

```
SHLL [/] # id
uid=0(root),gid=0(root),euid=0(root),egid=0(root)
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_ID` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_ID` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `id` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_id(
    int    argc,
    char **argv
);
```

The configuration structure for the `id` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_ID_Command;
```

2.2.6 `tty - show ttyname`

SYNOPSIS:

```
tty
```

DESCRIPTION:

This command prints the file name of the device connected to standard input.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `tty`:

```
SHLL [/] $ tty  
/dev/console
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_TTY` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_TTY` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `tty` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_tty(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the `tty` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_TTY_Command;
```

2.2.7 whoami - print effective user id

SYNOPSIS:

```
whoami
```

DESCRIPTION:

This command displays the user name associated with the current effective user id.

EXIT STATUS:

This command always succeeds.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `whoami`:

```
SHLL [/] $ whoami
rtems
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_WHOAMI` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_WHOAMI` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `whoami` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_whoami(
    int    argc,
    char **argv
);
```

The configuration structure for the `whoami` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_WHOAMI_Command;
```

2.2.8 logoff - logoff from the system

SYNOPSIS:

```
logoff
```

DESCRIPTION:

This command logs the user out of the shell.

EXIT STATUS:

This command does not return.

NOTES:

The system behavior when the shell is exited depends upon how the shell was initiated. The typical behavior is that a login prompt will be displayed for the next login attempt or that the connection will be dropped by the RTEMS system.

EXAMPLES:

The following is an example of how to use logoff:

```
SHLL [/] $ logoff
logoff from the system...
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_LOGOFF` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_LOGOFF` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `logoff` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_logoff(
    int    argc,
    char **argv
);
```

The configuration structure for the `logoff` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_LOGOFF_Command;
```

2.2.9 exit - exit the shell

SYNOPSIS:

```
exit
```

DESCRIPTION:

This command causes the shell interpreter to **exit**.

EXIT STATUS:

This command does not return.

NOTES:

In contrast to [Section 2.2.8 \[General Commands logoff - logoff from the system\]](#), page 16, this command is built into the shell interpreter loop.

EXAMPLES:

The following is an example of how to use **exit**:

```
SHLL [/] $ exit
Shell exiting
```

CONFIGURATION:

This command is always present and cannot be disabled.

PROGRAMMING INFORMATION:

The **exit** is implemented directly in the shell interpreter. There is no C routine associated with it.

3 File and Directory Commands

3.1 Introduction

The RTEMS shell has the following file and directory commands:

- `umask` - Set file mode creation mask
- `cp` - copy files
- `pwd` - print work directory
- `ls` - list files in the directory
- `chdir` - change the current directory
- `mkdir` - create a directory
- `rmdir` - remove empty directories
- `chroot` - change the root directory
- `chmod` - change permissions of a file
- `cat` - display file contents
- `msdosfmt` - format disk
- `rm` - remove files
- `mount` - mount disk
- `unmount` - unmount disk
- `blksync` - sync the block driver
- `dir` - alias for `ls`
- `cd` - alias for `chdir`

3.2 Commands

This section details the File and Directory Commands available. A subsection is dedicated to each of the commands and describes the behavior and configuration of that command as well as providing an example usage.

3.2.1 umask - set file mode creation mask

SYNOPSIS:

```
umask [new_umask]
```

DESCRIPTION:

This command sets the user file creation mask to `new_umask`. The argument `new_umask` may be octal, hexadecimal, or decimal.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

This command does not currently support symbolic mode masks.

EXAMPLES:

The following is an example of how to use `umask`:

```
SHLL [/] $ umask
022
SHLL [/] $ umask 0666
0666
SHLL [/] $ umask
0666
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_UMASK` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_UMASK` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `umask` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_umask(
    int    argc,
    char **argv
);
```

The configuration structure for the `umask` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_UMASK_Command;
```


3.2.2 cp - copy files

SYNOPSIS:

```
cp [-R [-H | -L | -P]] [-f | -i] [-pv] src target
```

```
cp [-R [-H | -L] ] [-f | -i] [-NpPv] source_file ... target_directory
```

DESCRIPTION:

In the first synopsis form, the cp utility copies the contents of the source_file to the target_file. In the second synopsis form, the contents of each named source_file is copied to the destination target_directory. The names of the files themselves are not changed. If cp detects an attempt to copy a file to itself, the copy will fail.

The following options are available:

-f

For each existing destination pathname, attempt to overwrite it. If permissions do not allow copy to succeed, remove it and create a new file, without prompting for confirmation. (The -i option is ignored if the -f option is specified.)

-H

If the -R option is specified, symbolic links on the command line are followed. (Symbolic links encountered in the tree traversal are not followed.)

-i

Causes cp to write a prompt to the standard error output before copying a file that would overwrite an existing file. If the response from the standard input begins with the character 'y', the file copy is attempted.

-L

If the -R option is specified, all symbolic links are followed.

-N

When used with -p, do not copy file flags.

-P

No symbolic links are followed.

-p

Causes cp to preserve in the copy as many of the modification time, access time, file flags, file mode, user ID, and group ID as allowed by permissions.

If the user ID and group ID cannot be preserved, no error message is displayed and the exit value is not altered.

If the source file has its set user ID bit on and the user ID cannot be preserved, the set user ID bit is not preserved in the copy's permissions. If the source file has its set group ID bit on and the group

ID cannot be preserved, the set group ID bit is not preserved in the copy's permissions. If the source file has both its set user ID and set group ID bits on, and either the user ID or group ID cannot be preserved, neither the set user ID or set group ID bits are preserved in the copy's permissions.

-R

If `source_file` designates a directory, `cp` copies the directory and the entire subtree connected at that point. This option also causes symbolic links to be copied, rather than indirected through, and for `cp` to create special files rather than copying them as normal files. Created directories have the same mode as the corresponding source directory, unmodified by the process's `umask`.

-v

Cause `cp` to be verbose, showing files as they are copied.

For each destination file that already exists, its contents are overwritten if permissions allow, but its mode, user ID, and group ID are unchanged.

In the second synopsis form, `target_directory` must exist unless there is only one named `source_file` which is a directory and the `-R` flag is specified.

If the destination file does not exist, the mode of the source file is used as modified by the file mode creation mask (`umask`, see `cs(1)`). If the source file has its set user ID bit on, that bit is removed unless both the source file and the destination file are owned by the same user. If the source file has its set group ID bit on, that bit is removed unless both the source file and the destination file are in the same group and the user is a member of that group. If both the set user ID and set group ID bits are set, all of the above conditions must be fulfilled or both bits are removed.

Appropriate permissions are required for file creation or overwriting.

Symbolic links are always followed unless the `-R` flag is set, in which case symbolic links are not followed, by default. The `-H` or `-L` flags (in conjunction with the `-R` flag), as well as the `-P` flag cause symbolic links to be followed as described above. The `-H` and `-L` options are ignored unless the `-R` option is specified. In addition, these options override eachsubhedading other and the command's actions are determined by the last one specified.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `cp` to copy a file to a new name in the current directory:

```
SHLL [/] # cat joel
```

```

cat: joel: No such file or directory
SHLL [/] # cp etc/passwd joel
SHLL [/] # cat joel
root*:~:0:0:root::~:/bin/sh
rtems*:~:1:1:RTEMS Application::~:/bin/sh
tty!:~:2:2:tty owner::~:/bin/false
SHLL [/] # ls
drwxr-xr-x  1  root  root           536 Jan 01 00:00 dev/
drwxr-xr-x  1  root  root          1072 Jan 01 00:00 etc/
-rw-r--r--  1  root  root           102 Jan 01 00:00 joel
3 files 1710 bytes occupied

```

The following is an example of how to use `cp` to copy one or more files to a destination directory and use the same basename in the destination directory:

```

SHLL [/] # mkdir tmp
SHLL [/] # ls tmp
0 files 0 bytes occupied
SHLL [/] # cp /etc/passwd tmp
SHLL [/] # ls /tmp
-rw-r--r--  1  root  root           102 Jan 01 00:01 passwd
1 files 102 bytes occupied
SHLL [/] # cp /etc/passwd /etc/group /tmp
SHLL [/] # ls /tmp
-rw-r--r--  1  root  root           102 Jan 01 00:01 passwd
-rw-r--r--  1  root  root            42 Jan 01 00:01 group
2 files 144 bytes occupied
SHLL [/] #

```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_CP` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_CP` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `cp` is implemented by a C language function which has the following prototype:

```

int rtems_shell_rtems_main_cp(
    int  argc,
    char **argv
);

```

The configuration structure for the `cp` has the following prototype:

```

extern rtems_shell_cmd_t rtems_shell_CP_Command;

```

ORIGIN:

The implementation and portions of the documentation for this command are from NetBSD 4.0.

3.2.3 pwd - print work directory

SYNOPSIS:

```
pwd
```

DESCRIPTION:

This command prints the fully qualified filename of the current working directory.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `pwd`:

```
SHLL [/] $ pwd
/
SHLL [/] $ cd dev
SHLL [/dev] $ pwd
/dev
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_PWD` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_PWD` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `pwd` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_pwd(
    int    argc,
    char **argv
);
```

The configuration structure for the `pwd` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_PWD_Command;
```

3.2.4 ls - list files in the directory

SYNOPSIS:

```
ls [dir]
```

DESCRIPTION:

This command displays the contents of the specified directory. If no arguments are given, then it displays the contents of the current working directory.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

This command currently does not display information on a set of files like the POSIX `ls(1)`. It only displays the contents of entire directories.

EXAMPLES:

The following is an example of how to use `ls`:

```
SHLL [/] $ ls
drwxr-xr-x  1  root  root           536 Jan 01 00:00 dev/
drwxr-xr-x  1  root  root          1072 Jan 01 00:00 etc/
2 files 1608 bytes occupied
SHLL [/] $ ls etc
-rw-r--r--  1  root  root           102 Jan 01 00:00 passwd
-rw-r--r--  1  root  root            42 Jan 01 00:00 group
-rw-r--r--  1  root  root            30 Jan 01 00:00 issue
-rw-r--r--  1  root  root            28 Jan 01 00:00 issue.net
4 files 202 bytes occupied
SHLL [/] $ ls dev etc
-rwxr-xr-x  1  rtems  root            0 Jan 01 00:00 console
-rwxr-xr-x  1  root   root            0 Jan 01 00:00 console_b
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_LS` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_LS` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `ls` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_ls(
    int  argc,
    char **argv
);
```

The configuration structure for the `ls` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_LS_Command;
```

3.2.5 chdir - change the current directory

SYNOPSIS:

```
chdir [dir]
```

DESCRIPTION:

This command is used to change the current working directory to the specified directory. If no arguments are given, the current working directory will be changed to `/`.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `chdir`:

```
SHLL [/] $ pwd
/
SHLL [/] $ chdir etc
SHLL [/etc] $ pwd
/etc
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_CHDIR` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_CHDIR` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `chdir` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_chdir(
    int    argc,
    char **argv
);
```

The configuration structure for the `chdir` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_CHDIR_Command;
```


3.2.6 mkdir - create a directory

SYNOPSIS:

```
mkdir dir [dir1 .. dirN]
```

DESCRIPTION:

This command creates the set of directories in the order they are specified on the command line. If an error is encountered making one of the directories, the command will continue to attempt to create the remaining directories on the command line.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

If this command is invoked with no arguments, nothing occurs.

The user must have sufficient permissions to create the directory. For the `fileio` test provided with RTEMS, this means the user must login as `root` not `rtems`.

EXAMPLES:

The following is an example of how to use `mkdir`:

```
SHLL [/] # ls
drwxr-xr-x  1  root  root           536 Jan 01 00:00 dev/
drwxr-xr-x  1  root  root          1072 Jan 01 00:00 etc/
2 files 1608 bytes occupied
SHLL [/] # mkdir joel
SHLL [/] # ls joel
0 files 0 bytes occupied
SHLL [/] # cp etc/passwd joel
SHLL [/] # ls joel
-rw-r--r--  1  root  root           102 Jan 01 00:02 passwd
1 files 102 bytes occupied
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_MKDIR` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_MKDIR` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `mkdir` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_mkdir(
    int  argc,
    char **argv
);
```

The configuration structure for the `mkdir` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_MKDIR_Command;
```

3.2.7 rmdir - remove empty directories

SYNOPSIS:

```
rmdir [dir1 .. dirN]
```

DESCRIPTION:

This command removes the specified set of directories. If no directories are provided on the command line, no actions are taken.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

This command is implemented using the `rmdir(2)` system call and all reasons that call may fail apply to this command.

EXAMPLES:

The following is an example of how to use `rmdir`:

```
SHLL [/] # mkdir joeldir
SHLL [/] # rmdir joeldir
SHLL [/] # ls joeldir
joeldir: No such file or directory.
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_RMDIR` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_RMDIR` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `rmdir` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_rmdir(
    int    argc,
    char **argv
);
```

The configuration structure for the `rmdir` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_RMDIR_Command;
```

3.2.8 chroot - change the root directory

SYNOPSIS:

```
chroot [dir]
```

DESCRIPTION:

This command changes the root directory to `dir` for subsequent commands.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

The destination directory `dir` must exist.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `chroot` and the impact it has on the environment for subsequent command invocations:

```
SHLL [/] $ cat passwd
cat: passwd: No such file or directory
SHLL [/] $ chroot etc
SHLL [/] $ cat passwd
root:*:0:0:root:::/bin/sh
rtems:*:1:1:RTEMS Application:::/bin/sh
tty!:2:2:tty owner:::/bin/false
SHLL [/] $ cat /etc/passwd
cat: /etc/passwd: No such file or directory
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_CHROOT` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_CHROOT` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `chroot` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_chroot(
    int    argc,
    char **argv
);
```

The configuration structure for the `chroot` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_CHROOT_Command;
```

3.2.9 chmod - change permissions of a file

SYNOPSIS:

```
chmod permissions file1 [file2...]
```

DESCRIPTION:

This command changes the permissions on the files specified to the indicated **permissions**. The permission values are POSIX based with owner, group, and world having individual read, write, and executive permission bits.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

The `chmod` command only takes numeric representations of the permissions.

EXAMPLES:

The following is an example of how to use `chmod`:

```
SHLL [/] # cd etc
SHLL [/etc] # ls
-rw-r--r--  1  root  root           102 Jan 01 00:00 passwd
-rw-r--r--  1  root  root           42 Jan 01 00:00 group
-rw-r--r--  1  root  root           30 Jan 01 00:00 issue
-rw-r--r--  1  root  root           28 Jan 01 00:00 issue.net
4 files 202 bytes occupied
SHLL [/etc] # chmod 0777 passwd
SHLL [/etc] # ls
-rwxrwxrwx  1  root  root           102 Jan 01 00:00 passwd
-rw-r--r--  1  root  root           42 Jan 01 00:00 group
-rw-r--r--  1  root  root           30 Jan 01 00:00 issue
-rw-r--r--  1  root  root           28 Jan 01 00:00 issue.net
4 files 202 bytes occupied
SHLL [/etc] # chmod 0322 passwd
SHLL [/etc] # ls
--wx-w--w-  1 nouser  root           102 Jan 01 00:00 passwd
-rw-r--r--  1 nouser  root           42 Jan 01 00:00 group
-rw-r--r--  1 nouser  root           30 Jan 01 00:00 issue
-rw-r--r--  1 nouser  root           28 Jan 01 00:00 issue.net
4 files 202 bytes occupied
SHLL [/etc] # chmod 0644 passwd
SHLL [/etc] # ls
-rw-r--r--  1  root  root           102 Jan 01 00:00 passwd
-rw-r--r--  1  root  root           42 Jan 01 00:00 group
-rw-r--r--  1  root  root           30 Jan 01 00:00 issue
-rw-r--r--  1  root  root           28 Jan 01 00:00 issue.net
4 files 202 bytes occupied
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_CHMOD` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_CHMOD` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `chmod` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_chmod(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the `chmod` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_CHMOD_Command;
```

3.2.10 cat - display file contents

SYNOPSIS:

```
cat file1 [file2 .. fileN]
```

DESCRIPTION:

This command displays the contents of the specified files.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

It is possible to read the input from a device file using `cat`.

EXAMPLES:

The following is an example of how to use `cat`:

```
SHLL [/] # cat /etc/passwd
root*:0:0:root:::/bin/sh
rtems*:1:1:RTEMS Application:::/bin/sh
tty!:2:2:tty owner:::/bin/false
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_CAT` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_CAT` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `cat` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_cat(
    int    argc,
    char **argv
);
```

The configuration structure for the `cat` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_CAT_Command;
```

3.2.11 rm - remove files

SYNOPSIS:

```
rm file1 [file2 ... fileN]
```

DESCRIPTION:

This command deletes a name from the filesystem. If the specified file name was the last link to a file and there are no open file descriptor references to that file, then it is deleted and the associated space in the file system is made available for subsequent use.

If the filename specified was the last link to a file but there are open file descriptor references to it, then the file will remain in existence until the last file descriptor referencing it is closed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use rm:

```
SHLL [/] # cp /etc/passwd tmpfile
SHLL [/] # cat tmpfile
root:*:0:0:root:::/bin/sh
rtems:*:1:1:RTEMS Application:::/bin/sh
tty:!:2:2:tty owner:::/bin/false
SHLL [/] # rm tmpfile
SHLL [/] # cat tmpfile
cat: tmpfile: No such file or directory
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_RM` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_RM` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `rm` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_rm(
    int    argc,
    char **argv
);
```

The configuration structure for the `rm` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_RM_Command;
```


3.2.12 mount - mount disk

SYNOPSIS:

```
mount [-t fstype] [-r] [-L] device path
```

DESCRIPTION:

The `mount` command will mount a block device to a mount point using the specified file system. The file systems are:

- `msdos` - MSDOS File System
- `tftp` - TFTP Network File System
- `ftp` - FTP Network File System
- `nfs` - Network File System

When the file system type is `'msdos'` the driver is a "block device driver" node present in the file system. The driver is ignored with the `'tftp'` and `'ftp'` file systems. For the `'nfs'` file system the driver is the `'host:/path'` string that described NFS host and the exported file system path.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

The mount point must exist.

The services offered by each file-system vary. For example you cannot list the directory of a TFTP file-system as this server is not provided in the TFTP protocol. You need to check each file-system's documentation for the services provided.

EXAMPLES:

Mount the Flash Disk driver to the `'/fd'` mount point:

```
$ mount -t msdos /dev/flashdisk0 /fd
```

Mount the NFS file system exported path `'bar'` by host `'foo'`:

```
$ mount -t nfs foo:/bar /nfs
```

Mount the TFTP file system on `'/tftp'`:

```
$ mount -t tftp /tftp
```

To access the TFTP files on server `'10.10.10.10'`:

```
$ cat /tftp/10.10.10.10/test.txt
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_MOUNT` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_MOUNT` when all shell commands have been configured.

The mount command includes references to file-system code. If you do not wish to include file-system that you do not use do not define the mount command support for that file-system. The file-system mount command defines are:

- msdos - `CONFIGURE_SHELL_MOUNT_MSDOS`
- tftp - `CONFIGURE_SHELL_MOUNT_TFTP`
- ftp - `CONFIGURE_SHELL_MOUNT_FTP`
- nfs - `CONFIGURE_SHELL_MOUNT_NFS`

An example configuration is:

```
#define CONFIGURE_SHELL_MOUNT_MSDOS
#ifdef RTEMS_NETWORKING
    #define CONFIGURE_SHELL_MOUNT_TFTP
    #define CONFIGURE_SHELL_MOUNT_FTP
    #define CONFIGURE_SHELL_MOUNT_NFS
#endif
```

PROGRAMMING INFORMATION:

The mount is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_mount(
    int    argc,
    char **argv
);
```

The configuration structure for the mount has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_MOUNT_Command;
```

3.2.13 unmount - unmount disk

SYNOPSIS:

```
unmount path
```

DESCRIPTION:

This command unmounts the device at the specified `path`.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

TBD - Surely there must be some warnings to go here.

EXAMPLES:

The following is an example of how to use `unmount`:

```
EXAMPLE_TBD
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_UNMOUNT` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_UNMOUNT` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `unmount` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_unmount(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the `unmount` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_UNMOUNT_Command;
```

3.2.14 blksync - sync the block driver

SYNOPSIS:

```
blksync driver
```

DESCRIPTION:

This command XXX

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use blksync:

```
EXAMPLE_TBD
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_BLKSYNC` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_BLKSYNC` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The blksync is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_blksync(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the blksync has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_BLKSYNC_Command;
```

3.2.15 dir - alias for ls

SYNOPSIS:

```
dir [dir]
```

DESCRIPTION:

This command is an alias or alternate name for the `ls`. See [Section 3.2.4 \[File and Directory Commands `ls` - list files in the directory\]](#), page 26 for more information.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `dir`:

```
SHLL [/] $ dir
drwxr-xr-x  1  root  root           536 Jan 01 00:00 dev/
drwxr-xr-x  1  root  root          1072 Jan 01 00:00 etc/
2 files 1608 bytes occupied
SHLL [/] $ dir etc
-rw-r--r--  1  root  root           102 Jan 01 00:00 passwd
-rw-r--r--  1  root  root            42 Jan 01 00:00 group
-rw-r--r--  1  root  root            30 Jan 01 00:00 issue
-rw-r--r--  1  root  root            28 Jan 01 00:00 issue.net
4 files 202 bytes occupied
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_DIR` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_DIR` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `dir` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_dir(
    int  argc,
    char **argv
);
```

The configuration structure for the `dir` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_DIR_Command;
```

3.2.16 cd - alias for chdir

SYNOPSIS:

```
cd directory
```

DESCRIPTION:

This command is an alias or alternate name for the `chdir`. See [Section 3.2.5 \[File and Directory Commands `chdir` - change the current directory\]](#), page 28 for more information.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `cd`:

```
SHLL [/] $ cd etc
SHLL [/etc] $ cd /
SHLL [/] $ cd /etc
SHLL [/etc] $ pwd
/etc
SHLL [/etc] $ cd /
SHLL [/] $ pwd
/
SHLL [/] $ cd etc
SHLL [/etc] $ cd ..
SHLL [/] $ pwd
/
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_CD` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_CD` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `cd` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_cd(
    int    argc,
    char **argv
);
```

The configuration structure for the `cd` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_CD_Command;
```

4 Memory Commands

4.1 Introduction

The RTEMS shell has the following memory commands:

- `mdump` - Display contents of memory
- `wdump` - Display contents of memory (word)
- `medit` - Modify contents of memory
- `mfill` - Fill memory with pattern
- `mmove` - Move contents of memory
- `malloc` - Obtain information on C Program Heap

4.2 Commands

This section details the Memory Commands available. A subsection is dedicated to each of the commands and describes the behavior and configuration of that command as well as providing an example usage.

4.2.1 mdump - display contents of memory

SYNOPSIS:

```
mdump [address [length]]
```

DESCRIPTION:

This command displays the contents of memory at the `address` and `length` in bytes specified on the command line.

When `length` is not provided, it defaults to 320 which is twenty lines of output with sixteen bytes of output per line.

When `address` is not provided, it defaults to 0x00000000.

EXIT STATUS:

This command always returns 0 to indicate success.

NOTES:

Dumping memory from a non-existent address may result in an unrecoverable program fault.

EXAMPLES:

The following is an example of how to use `mdump`:

```
SHLL [/] $ mdump 0x10000 32
0x0001000000 00 00 00 00 00 00 00 00-00 00 00 00 00 00 00 00 .....
0x0001001000 00 00 00 00 00 00 00 00-00 00 00 00 00 00 00 00 .....
SHLL [/] $ mdump 0x02000000 32
0x02000000A1 48 00 00 29 00 80 33-81 C5 22 BC A6 10 21 00 .H..)3..".!..
0x02000010A1 48 00 00 29 00 80 33-81 C5 22 BC A6 10 21 01 .H..)3..".!..
SHLL [/] $ mdump 0x02001000 32
0x0200100003 00 80 00 82 10 60 00-81 98 40 00 83 48 00 00 ..... '.....H..
0x0200101084 00 60 01 84 08 A0 07-86 10 20 01 87 28 C0 02 ..'..... ..(..
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_MDUMP` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_MDUMP` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `mdump` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_mdump(
    int    argc,
    char **argv
);
```

The configuration structure for the `mdump` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_MDUMP_Command;
```


4.2.2 wdump - display contents of memory (word)

SYNOPSIS:

```
wdump [address [length]]
```

DESCRIPTION:

This command displays the contents of memory at the `address` and `length` in bytes specified on the command line.

When `length` is not provided, it defaults to 320 which is twenty lines of output with sixteen bytes of output per line.

When `address` is not provided, it defaults to 0x00000000.

EXIT STATUS:

This command always returns 0 to indicate success.

NOTES:

Dumping memory from a non-existent address may result in an unrecoverable program fault.

EXAMPLES:

The following is an example of how to use `wdump`:

```
SHLL [/] $ wdump 0x02010000 32
0x02010000 0201 08D8 0201 08C0-0201 08AC 0201 0874 .....t
0x02010010 0201 0894 0201 0718-0201 0640 0201 0798 .....
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_WDUMP` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_WDUMP` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `wdump` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_wdump(
    int    argc,
    char **argv
);
```

The configuration structure for the `wdump` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_WDUMP_Command;
```

4.2.3 medit - modify contents of memory

SYNOPSIS:

```
medit address value1 [value2 ... valueN]
```

DESCRIPTION:

This command is used to modify the contents of the memory starting at `address` using the octets specified by the parameters `value1` through `valueN`.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

Dumping memory from a non-existent address may result in an unrecoverable program fault.

EXAMPLES:

The following is an example of how to use `medit`:

```
SHLL [/] $ mdump 0x02000000 32
0x02000000 A1 48 00 00 29 00 80 33-81 C5 22 BC A6 10 21 00 .H...)..3.."...!.
0x02000010 A1 48 00 00 29 00 80 33-81 C5 22 BC A6 10 21 01 .H...)..3.."...!.
SHLL [/] $ medit 0x02000000 0x01 0x02 0x03 0x04 0x05 0x06 0x07 0x08 0x09
SHLL [/] $ mdump 0x02000000 32
0x02000000 01 02 03 04 05 06 07 08-09 00 22 BC A6 10 21 00 ....."....!.
0x02000010 A1 48 00 00 29 00 80 33-81 C5 22 BC A6 10 21 01 .H...)..3.."...!.
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_MEDIT` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_MEDIT` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `medit` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_medit(
    int    argc,
    char **argv
);
```

The configuration structure for the `medit` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_MEDIT_Command;
```

4.2.4 mfill - file memory with pattern

SYNOPSIS:

```
mfill address length value
```

DESCRIPTION:

This command is used to fill the memory starting at `address` for the specified `length` in octets when the specified at `value`.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

Filling a non-existent address range may result in an unrecoverable program fault. Similarly overwriting interrupt vector tables, code space or critical data areas can be fatal as shown in the example.

EXAMPLES:

In this example, the address used (0x23d89a0) as the base address of the filled area is the end of the stack for the Idle thread. This address was determined manually using gdb and is very specific to this application and BSP. The first command in this example is an `mdump` to display the initial contents of this memory. We see that the first 8 bytes are 0xA5 which is the pattern used as a guard by the Stack Checker. On the first context switch after the pattern is overwritten by the `mfill` command, the Stack Checker detect the pattern has been corrupted and generates a fatal error.

```
SHLL [/] $ mdump 0x23d89a0 16
0x023D89A0 A5 A5 A5 A5 A5 A5 A5 A5-FE ED FO OD OB AD OD O6 .....
SHLL [/] $ mfill 0x23d89a0 13 0x5a
SHLL [/] $ BLOWN STACK!!! Offending task(0x23D4418): id=0x09010001; name=0x0203D908
stack covers range 0x23D89A0 - 0x23D99AF (4112 bytes)
Damaged pattern begins at 0x023D89A8 and is 16 bytes long
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_MFILL` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_MFILL` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `mfill` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_mfill(
    int    argc,
    char **argv
);
```

The configuration structure for the `mfill` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_MFILL_Command;
```

4.2.5 mmove - move contents of memory

SYNOPSIS:

```
mmove dst src length
```

DESCRIPTION:

This command is used to copy the contents of the memory starting at `src` to the memory located at `dst` for the specified `length` in octets.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `mmove`:

```
SHLL [/] $ mdump 0x023d99a0 16
0x023D99A0 A5 A5 A5 A5 A5 A5 A5 A5-A5 A5 A5 A5 A5 A5 A5 .....
SHLL [/] $ mdump 0x02000000 16
0x02000000 A1 48 00 00 29 00 80 33-81 C5 22 BC A6 10 21 00 .H..)3..!..
SHLL [/] $ mmove 0x023d99a0 0x02000000 13
SHLL [/] $ mdump 0x023d99a0 16
0x023D99A0 A1 48 00 00 29 00 80 33-81 C5 22 BC A6 A5 A5 A5 .H..)3..!.....
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_MMOVE` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_MMOVE` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `mmove` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_mmove(
    int    argc,
    char **argv
);
```

The configuration structure for the `mmove` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_MMOVE_Command;
```

4.2.6 malloc - obtain information on C program heap

SYNOPSIS:

```
malloc [info|stats]
```

DESCRIPTION:

This command prints either information or statistics about the C Program Heap used by the `malloc` family of calls based upon the value of the first argument passed to the command.

When the subcommand `info` is specified, information on the current state of the C Program Heap is reported. This includes the following information:

- Number of free blocks
- Largest free block
- Total bytes free
- Number of used blocks
- Largest used block
- Total bytes used

When the subcommand `stats` is specified, statistics on the the C Program Heap are reported. Malloc Family Statistics must be enabled for all of the values to be updated. The statistics available includes the following information:

-
- Currently available memory (in kilobytes)
- Currently allocated memory (in kilobytes)
- Maximum amount of memory ever allocated (in kilobytes)
- Lifetime tally of allocated memory (in kilobytes)
- Lifetime tally of freed memory (in kilobytes)
- Number of calls to `malloc`
- Number of calls to `free`
- Number of calls to `realloc`
- Number of calls to `calloc`

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

The `CONFIGURE_MALLOC_STATISTICS` `confdefs.h` constant must be defined when the application is configured for the full set of statistics information to be available.

EXAMPLES:

The following is an example of how to use the `malloc` command.

```

SHLL [/] $ malloc info
Number of free blocks: 3
Largest free block:    3626672
Total bytes free:     3627768
Number of used blocks: 130
Largest used block:   1048
Total bytes used:     10136
SHLL [/] $ malloc stats
Malloc statistics
  avail:3552k  allocated:9k (0%) max:10k (0%) lifetime:21k freed:12k
  Call counts:  malloc:203  free:93  realloc:0  calloc:20
SHLL [/] $ malloc info
Number of free blocks: 3
Largest free block:    3626672
Total bytes free:     3627768
Number of used blocks: 130
Largest used block:   1048
Total bytes used:     10136
SHLL [/] $ malloc stats
Malloc statistics
  avail:3552k  allocated:9k (0%) max:10k (0%) lifetime:23k freed:14k
  Call counts:  malloc:205  free:95  realloc:0  calloc:20

```

Note that in the above example, the lifetime allocated and free values have increased between the two calls to `malloc stats` even though the amount of memory available in the C Program Heap is the same in both the `malloc info` invocations. This indicates that memory was allocated and freed as a side-effect of the commands.

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_MALLOC` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_MALLOC` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `malloc` is implemented by a C language function which has the following prototype:

```

int rtems_shell_rtems_main_malloc(
    int  argc,
    char **argv
);

```

The configuration structure for the `malloc` has the following prototype:

```

extern rtems_shell_cmd_t rtems_shell_MALLOC_Command;

```


5 RTEMS Specific Commands

5.1 Introduction

The RTEMS shell has the following rtems commands:

- `cpuuse` - print or reset per thread cpu usage
- `stackuse` - print per thread stack usage
- `perioduse` - print or reset per period usage
- `wkspc` - Display information on Executive Workspace
- `config` - Show the system configuration.
- `itask` - List init tasks for the system
- `extension` - Display information about extensions
- `task` - Display information about tasks
- `queue` - Display information about message queues
- `sema` - display information about semaphores
- `region` - display information about regions
- `part` - display information about partitions
- `object` - Display information about RTEMS objects
- `driver` - Display the RTEMS device driver table
- `dname` - Displays information about named drivers
- `pthread` - Displays information about POSIX threads

5.2 Commands

This section details the RTEMS Specific Commands available. A subsection is dedicated to each of the commands and describes the behavior and configuration of that command as well as providing an example usage.

5.2.1 `cpuuse` - print or reset per thread cpu usage

SYNOPSIS:

```
cpuuse [-r]
```

DESCRIPTION:

This command may be used to print a report on the per thread cpu usage or to reset the per thread CPU usage statistics. When invoked with the `-r` option, the CPU usage statistics are reset.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

The granularity of the timing information reported is dependent upon the BSP and the manner in which RTEMS was built. In the default RTEMS configuration, if the BSP supports nanosecond granularity timestamps, then the information reported will be highly accurate. Otherwise, the accuracy of the information reported is limited by the clock tick quantum.

EXAMPLES:

The following is an example of how to use `cpuuse`:

```
SHLL [/] $ cpuuse
CPU Usage by thread
  ID          NAME          SECONDS  PERCENT
0x09010001  IDLE          49.745393  98.953
0x0a010001  UI1           0.000000  0.000
0x0a010002  SHLL          0.525928  1.046
Time since last CPU Usage reset 50.271321 seconds
SHLL [/] $ cpuuse -r
Resetting CPU Usage information
SHLL [/] $ cpuuse
CPU Usage by thread
  ID          NAME          SECONDS  PERCENT
0x09010001  IDLE          0.000000  0.000
0x0a010001  UI1           0.000000  0.000
0x0a010002  SHLL          0.003092  100.000
Time since last CPU Usage reset 0.003092 seconds
```

In the above example, the system had set idle for nearly a minute when the first report was generated. The `cpuuse -r` and `cpuuse` commands were pasted from another window so were executed with no gap between. In the second report, only the `shell` thread has run since the CPU Usage was reset. It has consumed approximately 3.092 milliseconds of CPU time processing the two commands and generating the output.

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_CPUUSE` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_CPUUSE` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `cpuuse` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_cpuuse(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the `cpuuse` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_CPUUSE_Command;
```

5.2.2 stackuse - print per thread stack usage

SYNOPSIS:

```
stackuse
```

DESCRIPTION:

This command prints a Stack Usage Report for all of the tasks and threads in the system. On systems which support it, the usage of the interrupt stack is also included in the report.

EXIT STATUS:

This command always succeeds and returns 0.

NOTES:

The `STACK_CHECKER_ON` `confdefs.h` constant must be defined when the application is configured for this command to have any information to report.

EXAMPLES:

The following is an example of how to use `stackuse`:

```
SHLL [/] $ stackuse
Stack usage by thread
  ID      NAME  LOW          HIGH         CURRENT      AVAILABLE    USED
0x09010001 IDLE 0x023d89a0 - 0x023d99af 0x023d9760    4096         608
0x0a010001 UI1  0x023d9f30 - 0x023daf3f 0x023dad18    4096        1804
0x0a010002 SHLL 0x023db4c0 - 0x023df4cf 0x023de9d0   16384        5116
0xffffffff INTR 0x023d2760 - 0x023d375f 0x00000000    4080         316
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_STACKUSE` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_STACKUSE` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `stackuse` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_stackuse(
    int    argc,
    char **argv
);
```

The configuration structure for the `stackuse` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_STACKUSE_Command;
```

5.2.3 perioduse - print or reset per period usage

SYNOPSIS:

```
perioduse [-r]
```

DESCRIPTION:

This command may be used to print a statistics report on the rate monotonic periods in the application or to reset the rate monotonic period usage statistics. When invoked with the `-r` option, the usage statistics are reset.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

The granularity of the timing information reported is dependent upon the BSP and the manner in which RTEMS was built. In the default RTEMS configuration, if the BSP supports nanosecond granularity timestamps, then the information reported will be highly accurate. Otherwise, the accuracy of the information reported is limited by the clock tick quantum.

EXAMPLES:

The following is an example of how to use `perioduse`:

```
SHLL [/] $ perioduse
Period information by period
--- CPU times are in seconds ---
--- Wall times are in seconds ---
      ID      OWNER COUNT MISSED      CPU TIME      WALL TIME
      MIN/MAX/AVG      MIN/MAX/AVG
0x42010001 TA1      502      0 0:000039/0:042650/0:004158 0:000039/0:020118/0:002848
0x42010002 TA2      502      0 0:000041/0:042657/0:004309 0:000041/0:020116/0:002848
0x42010003 TA3      501      0 0:000041/0:041564/0:003653 0:000041/0:020003/0:002814
0x42010004 TA4      501      0 0:000043/0:044075/0:004911 0:000043/0:020004/0:002814
0x42010005 TA5       10      0 0:000065/0:005413/0:002739 0:000065/1:000457/0:041058
      MIN/MAX/AVG      MIN/MAX/AVG

SHLL [/] $ perioduse -r
Resetting Period Usage information
SHLL [/] $ perioduse
--- CPU times are in seconds ---
--- Wall times are in seconds ---
      ID      OWNER COUNT MISSED      CPU TIME      WALL TIME
      MIN/MAX/AVG      MIN/MAX/AVG
0x42010001 TA1         0         0
0x42010002 TA2         0         0
0x42010003 TA3         0         0
0x42010004 TA4         0         0
0x42010005 TA5         0         0
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_PERIODUSE` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_PERIODUSE` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `perioduse` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_perioduse(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the `perioduse` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_PERIODUSE_Command;
```

5.2.4 `wkspc` - display information on executive workspace

SYNOPSIS:

```
wkspc
```

DESCRIPTION:

This command prints information on the current state of the RTEMS Executive Workspace reported. This includes the following information:

- Number of free blocks
- Largest free block
- Total bytes free
- Number of used blocks
- Largest used block
- Total bytes used

EXIT STATUS:

This command always succeeds and returns 0.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `wkspc`:

```
SHLL [/] $ wkspc
Number of free blocks: 1
Largest free block:   132336
Total bytes free:    132336
Number of used blocks: 36
Largest used block:  16408
Total bytes used:    55344
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_WKSPACE` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_WKSPACE` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `wkspc` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_wkspc(
    int  argc,
    char **argv
);
```

The configuration structure for the `wkspc` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_WKSPACE_Command;
```


5.2.5 config - show the system configuration.

SYNOPSIS:

```
config
```

DESCRIPTION:

This command display information about the RTEMS Configuration.

EXIT STATUS:

This command always succeeds and returns 0.

NOTES:

At this time, it does not report every configuration parameter. This is an area in which user submissions or sponsorship of a developer would be appreciated.

EXAMPLES:

The following is an example of how to use `config`:

```
INITIAL (startup) Configuration Info
-----
WORKSPACE      start: 0x23d22e0;  size: 0x2dd20
TIME           usec/tick: 10000;  tick/timeslice: 50;  tick/sec: 100
MAXIMUMS       tasks: 20;  timers: 0;  sems: 50;  que's: 20;  ext's: 1
                partitions: 0;  regions: 0;  ports: 0;  periods: 0
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_CONFIG` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_CONFIG` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `config` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_config(
    int  argc,
    char **argv
);
```

The configuration structure for the `config` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_CONFIG_Command;
```

5.2.6 itask - list init tasks for the system

SYNOPSIS:

```
itask
```

DESCRIPTION:

This command prints a report on the set of initialization tasks and threads in the system.

EXIT STATUS:

This command always succeeds and returns 0.

NOTES:

At this time, it includes only Classic API Initialization Tasks. This is an area in which user submissions or sponsorship of a developer would be appreciated.

EXAMPLES:

The following is an example of how to use `itask`:

```
SHLL [/] $ itask
#  NAME  ENTRY      ARGUMENT  PRIO  MODES  ATTRIBUTES  STACK SIZE
-----
0  UI1    [0x2002258] 0 [0x0]    1    nP      DEFAULT    4096 [0x1000]
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_ITASK` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_ITASK` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `itask` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_itask(
    int  argc,
    char **argv
);
```

The configuration structure for the `itask` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_ITASK_Command;
```

5.2.7 extension - display information about extensions

SYNOPSIS:

```
extension [id [id ...] ]
```

DESCRIPTION:

When invoked with no arguments, this command prints information on the set of User Extensions currently active in the system.

If invoked with a set of ids as arguments, then just those objects are included in the information printed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of using the `extension` command on a system with no user extensions.

```
SHLL [/] $ extension
  ID      NAME
-----
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_EXTENSION` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_EXTENSION` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `extension` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_extension(
    int    argc,
    char **argv
);
```

The configuration structure for the `extension` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_EXTENSION_Command;
```

5.2.8 task - display information about tasks

SYNOPSIS:

```
task [id [id ...] ]
```

DESCRIPTION:

When invoked with no arguments, this command prints information on the set of Classic API Tasks currently active in the system.

If invoked with a set of ids as arguments, then just those objects are included in the information printed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use the `task` on an application with just two Classic API tasks:

```
SHLL [/] $ task
  ID      NAME  PRIO  STAT  MODES  EVENTS  WAITID  WAITARG  NOTES
-----
0a010001  UI1     1    SUSP  P:T:nA  NONE
0a010002  SHLL   100   READY P:T:nA  NONE
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_TASK` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_TASK` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `task` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_task(
    int  argc,
    char **argv
);
```

The configuration structure for the `task` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_TASK_Command;
```

5.2.9 queue - display information about message queues

SYNOPSIS:

```
queue [id [id ... ] ]
```

DESCRIPTION:

When invoked with no arguments, this command prints information on the set of Classic API Message Queues currently active in the system.

If invoked with a set of ids as arguments, then just those objects are included in the information printed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of using the `queue` command on a system with no Classic API Message Queues.

```
SHLL [/] $ queue
  ID      NAME  ATTRIBUTES  PEND  MAXPEND  MAXSIZE
-----
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_QUEUE` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_QUEUE` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `queue` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_queue(
    int    argc,
    char **argv
);
```

The configuration structure for the `queue` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_QUEUE_Command;
```

5.2.10 sema - display information about semaphores

SYNOPSIS:

```
sema [id [id ... ] ]
```

DESCRIPTION:

When invoked with no arguments, this command prints information on the set of Classic API Semaphores currently active in the system.

If invoked with a set of objects ids as arguments, then just those objects are included in the information printed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `sema`:

```
SHLL [/] $ sema
  ID      NAME  ATTR          PRICEIL CURR_CNT HOLDID
-----
1a010001  LBI0  PR:BI:IN      0         1  00000000
1a010002  TRmi  PR:BI:IN      0         1  00000000
1a010003  LBI00 PR:BI:IN      0         1  00000000
1a010004  TRia  PR:BI:IN      0         1  00000000
1a010005  TRoa  PR:BI:IN      0         1  00000000
1a010006  TRxa  <assoc.c: BAD NAME>  0         0  09010001
1a010007  LBI01 PR:BI:IN      0         1  00000000
1a010008  LBI02 PR:BI:IN      0         1  00000000
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_SEMA` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_SEMA` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `sema` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_sema(
    int    argc,
    char **argv
);
```

The configuration structure for the `sema` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_SEMA_Command;
```

5.2.11 region - display information about regions

SYNOPSIS:

```
region [id [id ... ] ]
```

DESCRIPTION:

When invoked with no arguments, this command prints information on the set of Classic API Regions currently active in the system.

If invoked with a set of object ids as arguments, then just those object are included in the information printed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of using the `region` command on a system with no user extensions.

```
SHLL [/] $ region
  ID      NAME  ATTR      STARTADDR LENGTH  PAGE_SIZE USED_BLOCKS
-----
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_REGION` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_REGION` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `region` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_region(
    int  argc,
    char **argv
);
```

The configuration structure for the `region` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_REGION_Command;
```

5.2.12 part - display information about partitions

SYNOPSIS:

```
part [id [id ... ] ]
```

DESCRIPTION:

When invoked with no arguments, this command prints information on the set of Classic API Partitions currently active in the system.

If invoked with a set of object ids as arguments, then just those objects are included in the information printed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of using the `part` command on a system with no user extensions.

```
SHLL [/] $ part
  ID      NAME  ATTR      STARTADDR LENGTH  BUF_SIZE  USED_BLOCKS
-----
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_PART` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_PART` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `part` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_part(
    int  argc,
    char **argv
);
```

The configuration structure for the `part` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_PART_Command;
```


5.2.13 object - display information about rtems objects

SYNOPSIS:

```
object [id [id ...] ]
```

DESCRIPTION:

When invoked with a set of object ids as arguments, then a report on those objects is printed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `object`:

```
SHLL [/] $ object 0a010001 1a010002
  ID      NAME  PRIO  STAT  MODES  EVENTS  WAITID  WAITARG  NOTES
-----
0a010001  UI1      1  SUSP  P:T:nA  NONE
  ID      NAME  ATTR          PRICEIL  CURR_CNT  HOLDID
-----
1a010002  TRmi    PR:BI:IN      0          1      00000000
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_OBJECT` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_OBJECT` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `object` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_object(
    int  argc,
    char **argv
);
```

The configuration structure for the `object` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_OBJECT_Command;
```

5.2.14 driver - display the rtems device driver table

SYNOPSIS:

```
driver [ major [ major ... ] ]
```

DESCRIPTION:

When invoked with no arguments, this command prints information on the set of Device Drivers currently active in the system.

If invoked with a set of major numbers as arguments, then just those Device Drivers are included in the information printed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `driver`:

```
SHLL [/] $ driver
  Major      Entry points
-----
  0          init: [0x200256c]; control: [0x20024c8]
            open: [0x2002518]; close: [0x2002504]
            read: [0x20024f0]; write: [0x20024dc]
  1          init: [0x20023fc]; control: [0x2002448]
            open: [0x0]; close: [0x0]
            read: [0x0]; write: [0x0]
SHLL [/] $
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_DRIVER` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_DRIVER` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `driver` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_driver(
    int    argc,
    char **argv
);
```

The configuration structure for the `driver` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_DRIVER_Command;
```

5.2.15 `dnname` - displays information about named drivers

SYNOPSIS:

```
dnname
```

DESCRIPTION:

This command XXX

WARNING! XXX This command does not appear to work as of 27 February 2008.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `dnname`:

```
EXAMPLE_TBD
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_DNAME` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_DNAME` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `dnname` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_dnname(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the `dnname` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_DNAME_Command;
```

5.2.16 pthread - display information about POSIX threads

SYNOPSIS:

```
pthread [id [id ...] ]
```

DESCRIPTION:

When invoked with no arguments, this command prints information on the set of POSIX API threads currently active in the system.

If invoked with a set of ids as arguments, then just those objects are included in the information printed.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

This command is only available when the POSIX API is configured.

EXAMPLES:

The following is an example of how to use the `task` on an application with four POSIX threads:

```
SHLL [/] $ pthread
  ID      NAME      PRI  STATE  MODES  EVENTS  WAITID  WAITARG  NOTES
-----
0b010002  Main             133  READY  P:T:nA  NONE    43010001 0x7b1148
0b010003  ISR              133  Wcvar  P:T:nA  NONE    43010003 0x7b1148
0b01000c                      133  READY  P:T:nA  NONE    33010002 0x7b1148
0b01000d                      133  Wmutex P:T:nA  NONE    33010002 0x7b1148
```

CONFIGURATION:

This command is part of the monitor commands which are always available in the shell.

PROGRAMMING INFORMATION:

This command is not directly available for invocation.

6 Network Commands

6.1 Introduction

The RTEMS shell has the following network commands:

- `netstats` - obtain network statistics
- `ifconfig` - configure a network interface
- `route` - show or manipulate the IP routing table

6.2 Commands

This section details the Network Commands available. A subsection is dedicated to each of the commands and describes the behavior and configuration of that command as well as providing an example usage.

6.2.1 netstats - obtain network statistics

SYNOPSIS:

```
netstats [-Aimfpcut]
```

DESCRIPTION:

This command is used to display various types of network statistics. The information displayed can be specified using command line arguments in various combinations. The arguments are interpreted as follows:

```
-A          print All statistics
-i          print Inet Routes
-m          print MBUF Statistics
-f          print IF Statistics
-p          print IP Statistics
-c          print ICMP Statistics
-u          print UDP Statistics
-t          print TCP Statistics
```

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

NONE

EXAMPLES:

The following is an example of how to use `netstats`:

The following is an example of using the `netstats` command to print the IP routing table:

```
[/] $ netstats -i
Destination  Gateway/Mask/Hw  Flags  Refs  Use  Expire  Interface
default     192.168.1.14    UGS    0     0    0    eth1
192.168.1.0  255.255.255.0   U      0     0    1    eth1
192.168.1.14 00:A0:C8:1C:EE:28 UHL    1     0   1219  eth1
192.168.1.51 00:1D:7E:0C:D0:7C UHL    0    840   1202  eth1
192.168.1.151 00:1C:23:B2:0F:BB UHL    1     23   1219  eth1
```

The following is an example of using the `netstats` command to print the MBUF statistics:

```
[/] $ netstats -m
***** MBUF STATISTICS *****
mbufs:2048  clusters: 128  free: 63
drops: 0    waits: 0  drains: 0
  free:1967      data:79      header:2      socket:0
  pcb:0          rtable:0    htable:0     atable:0
  soname:0       soopts:0    ftable:0     rights:0
  ifaddr:0      control:0   oobdata:0
```

The following is an example of using the `netstats` command to print the interface statistics:

```
[/] $ netstats -f
***** INTERFACE STATISTICS *****
**** eth1 ****
Ethernet Address: 00:04:9F:00:5B:21
Address:192.168.1.244   Broadcast Address:192.168.1.255   Net mask:255.255.255.0
Flags: Up Broadcast Running Active Multicast
Send queue limit:50   length:1   Dropped:0
      Rx Interrupts:889           Not First:0           Not Last:0
          Giant:0               Non-octet:0
          Bad CRC:0             Overrun:0             Collision:0
      Tx Interrupts:867           Deferred:0            Late Collision:0
      Retransmit Limit:0         Underrun:0            Misaligned:0
```

The following is an example of using the `netstats` command to print the IP statistics:

```
[/] $ netstats -p
***** IP Statistics *****
      total packets received           894
  packets rcvd for unreachable dest     13
datagrams delivered to upper level     881
      total ip packets generated here   871
```

The following is an example of using the `netstats` command to print the ICMP statistics:

```
[/] $ netstats -c
***** ICMP Statistics *****
          Type 0 sent           843
      number of responses       843
          Type 8 received       843
```

The following is an example of using the `netstats` command to print the UDP statistics:

```
[/] $ netstats -u
***** UDP Statistics *****
```

The following is an example of using the `netstats` command to print the TCP statistics:

```
[/] $ netstats -t
***** TCP Statistics *****
      connections accepted           1
      connections established        1
  segs where we tried to get rtt     34
      times we succeeded              35
      delayed acks sent              2
      total packets sent             37
      data packets sent              35
      data bytes sent                2618
      ack-only packets sent          2
      total packets received         47
  packets received in sequence       12
      bytes received in sequence     307
      rcvd ack packets               35
      bytes acked by rcvd acks       2590
      times hdr predict ok for acks   27
      times hdr predict ok for data pkts 10
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_NETSTATS` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_NETSTATS` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `netstats` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_netstats(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the `netstats` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_NETSTATS_Command;
```


6.2.2 ifconfig - configure a network interface

SYNOPSIS:

```
ifconfig
ifconfig interface
ifconfig interface [up|down]
ifconfig interface [netmask|pointtopoint|broadcast] IP
```

DESCRIPTION:

This command may be used to display information about the network interfaces in the system or configure them.

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

Just like its counterpart on GNU/Linux and BSD systems, this command is complicated. More example usages would be a welcome submission.

EXAMPLES:

The following is an example of how to use `ifconfig`:

```
***** INTERFACE STATISTICS *****
**** eth1 ****
Ethernet Address: 00:04:9F:00:5B:21
Address:192.168.1.244  Broadcast Address:192.168.1.255  Net mask:255.255.255.0
Flags: Up Broadcast Running Active Multicast
Send queue limit:50  length:1  Dropped:0
      Rx Interrupts:5391          Not First:0          Not Last:0
          Giant:0              Non-octet:0
          Bad CRC:0            Overrun:0            Collision:0
      Tx Interrupts:5256          Deferred:0           Late Collision:0
      Retransmit Limit:0         Underrun:0           Misaligned:0
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_IFCONFIG` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_IFCONFIG` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `ifconfig` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_ifconfig(
    int  argc,
    char **argv
);
```

The configuration structure for the `ifconfig` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_IFCONFIG_Command;
```

6.2.3 route - show or manipulate the ip routing table

SYNOPSIS:

```
route [subcommand] [args]
```

DESCRIPTION:

This command is used to display and manipulate the routing table. When invoked with no arguments, the current routing information is displayed. When invoked with the subcommands `add` or `del`, then additional arguments must be provided to describe the route.

Command templates include the following:

```
route [add|del] -net IP_ADDRESS gw GATEWAY_ADDRESS [netmask MASK]
route [add|del] -host IP_ADDRESS gw GATEWAY_ADDRESS [netmask MASK]
```

When not provided the netmask defaults to 255.255.255.0

EXIT STATUS:

This command returns 0 on success and non-zero if an error is encountered.

NOTES:

Just like its counterpart on GNU/Linux and BSD systems, this command is complicated. More example usages would be a welcome submission.

EXAMPLES:

The following is an example of how to use `route` to display, add, and delete a new route:

```
[/] $ route
Destination      Gateway/Mask/Hw  Flags    Refs      Use Expire Interface
default          192.168.1.14    UGS      0         0   0 eth1
192.168.1.0      255.255.255.0   U        0         0   1 eth1
192.168.1.14     00:A0:C8:1C:EE:28 UHL      1         0  1444 eth1
192.168.1.51     00:1D:7E:0C:D0:7C UHL      0        10844  1202 eth1
192.168.1.151    00:1C:23:B2:0F:BB UHL      2         37  1399 eth1
[/] $ route add -net 192.168.3.0 gw 192.168.1.14
[/] $ route
Destination      Gateway/Mask/Hw  Flags    Refs      Use Expire Interface
default          192.168.1.14    UGS      0         0   0 eth1
192.168.1.0      255.255.255.0   U        0         0   1 eth1
192.168.1.14     00:A0:C8:1C:EE:28 UHL      2         0  1498 eth1
192.168.1.51     00:1D:7E:0C:D0:7C UHL      0        14937  1202 eth1
192.168.1.151    00:1C:23:B2:0F:BB UHL      2         96  1399 eth1
192.168.3.0      192.168.1.14    UGS      0         0   0 eth1
[/] $ route del -net 192.168.3.0 gw 192.168.1.14
[/] $ route
Destination      Gateway/Mask/Hw  Flags    Refs      Use Expire Interface
default          192.168.1.14    UGS      0         0   0 eth1
192.168.1.0      255.255.255.0   U        0         0   1 eth1
192.168.1.14     00:A0:C8:1C:EE:28 UHL      1         0  1498 eth1
192.168.1.51     00:1D:7E:0C:D0:7C UHL      0        15945  1202 eth1
192.168.1.151    00:1C:23:B2:0F:BB UHL      2        117  1399 eth1
```

CONFIGURATION:

This command is included in the default shell command set. When building a custom command set, define `CONFIGURE_SHELL_COMMAND_ROUTE` to have this command included.

This command can be excluded from the shell command set by defining `CONFIGURE_SHELL_NO_COMMAND_ROUTE` when all shell commands have been configured.

PROGRAMMING INFORMATION:

The `route` is implemented by a C language function which has the following prototype:

```
int rtems_shell_rtems_main_route(  
    int    argc,  
    char **argv  
);
```

The configuration structure for the `route` has the following prototype:

```
extern rtems_shell_cmd_t rtems_shell_ROUTE_Command;
```

Function and Variable Index

C

CONFIGURE_MALLOC_STATISTICS	50
CONFIGURE_SHELL_COMMAND_ALIAS	8
CONFIGURE_SHELL_COMMAND_BLKSYNC	40
CONFIGURE_SHELL_COMMAND_CAT	35
CONFIGURE_SHELL_COMMAND_CD	42
CONFIGURE_SHELL_COMMAND_CHDIR	28
CONFIGURE_SHELL_COMMAND_CHMOD	34
CONFIGURE_SHELL_COMMAND_CHROOT	32
CONFIGURE_SHELL_COMMAND_CONFIG	61
CONFIGURE_SHELL_COMMAND_CP	23
CONFIGURE_SHELL_COMMAND_CPUUSE	55
CONFIGURE_SHELL_COMMAND_DATE	9
CONFIGURE_SHELL_COMMAND_DIR	41
CONFIGURE_SHELL_COMMAND_DNAME	71
CONFIGURE_SHELL_COMMAND_DRIVER	70
CONFIGURE_SHELL_COMMAND_ECHO	11
CONFIGURE_SHELL_COMMAND_EXTENSION	63
CONFIGURE_SHELL_COMMAND_ID	13
CONFIGURE_SHELL_COMMAND_IFCONFIG	77
CONFIGURE_SHELL_COMMAND_ITASK	62
CONFIGURE_SHELL_COMMAND_LOGOFF	16
CONFIGURE_SHELL_COMMAND_LS	26
CONFIGURE_SHELL_COMMAND_MALLOC	51
CONFIGURE_SHELL_COMMAND_MDUMP	44
CONFIGURE_SHELL_COMMAND_MEDIT	46
CONFIGURE_SHELL_COMMAND_MFILL	47
CONFIGURE_SHELL_COMMAND_MKDIR	29
CONFIGURE_SHELL_COMMAND_MMOVE	49
CONFIGURE_SHELL_COMMAND_MOUNT	37
CONFIGURE_SHELL_COMMAND_NETSTATS	76
CONFIGURE_SHELL_COMMAND_OBJECT	69
CONFIGURE_SHELL_COMMAND_PART	68
CONFIGURE_SHELL_COMMAND_PERIODUSE	57
CONFIGURE_SHELL_COMMAND_PWD	25
CONFIGURE_SHELL_COMMAND_QUEUE	65
CONFIGURE_SHELL_COMMAND_REGION	67
CONFIGURE_SHELL_COMMAND_RM	36
CONFIGURE_SHELL_COMMAND_RMDIR	31
CONFIGURE_SHELL_COMMAND_ROUTE	80
CONFIGURE_SHELL_COMMAND_SEMA	66
CONFIGURE_SHELL_COMMAND_SLEEP	12
CONFIGURE_SHELL_COMMAND_STACKUSE	56
CONFIGURE_SHELL_COMMAND_TASK	64
CONFIGURE_SHELL_COMMAND_TTY	14
CONFIGURE_SHELL_COMMAND_UMASK	20
CONFIGURE_SHELL_COMMAND_UNMOUNT	39
CONFIGURE_SHELL_COMMAND_WDUMP	45
CONFIGURE_SHELL_COMMAND_WHOAMI	15
CONFIGURE_SHELL_COMMAND_WKSPACE	59
CONFIGURE_SHELL_NO_COMMAND_ALIAS	8
CONFIGURE_SHELL_NO_COMMAND_BLKSYNC	40
CONFIGURE_SHELL_NO_COMMAND_CAT	35
CONFIGURE_SHELL_NO_COMMAND_CD	42
CONFIGURE_SHELL_NO_COMMAND_CHDIR	28
CONFIGURE_SHELL_NO_COMMAND_CHMOD	34
CONFIGURE_SHELL_NO_COMMAND_CHROOT	32
CONFIGURE_SHELL_NO_COMMAND_CONFIG	61
CONFIGURE_SHELL_NO_COMMAND_CP	23
CONFIGURE_SHELL_NO_COMMAND_CPUUSE	55
CONFIGURE_SHELL_NO_COMMAND_DATE	9
CONFIGURE_SHELL_NO_COMMAND_DIR	41
CONFIGURE_SHELL_NO_COMMAND_DNAME	71
CONFIGURE_SHELL_NO_COMMAND_DRIVER	70
CONFIGURE_SHELL_NO_COMMAND_ECHO	11
CONFIGURE_SHELL_NO_COMMAND_EXTENSION	63
CONFIGURE_SHELL_NO_COMMAND_ID	13
CONFIGURE_SHELL_NO_COMMAND_IFCONFIG	77
CONFIGURE_SHELL_NO_COMMAND_ITASK	62
CONFIGURE_SHELL_NO_COMMAND_LOGOFF	16
CONFIGURE_SHELL_NO_COMMAND_LS	26
CONFIGURE_SHELL_NO_COMMAND_MALLOC	51
CONFIGURE_SHELL_NO_COMMAND_MDUMP	44
CONFIGURE_SHELL_NO_COMMAND_MEDIT	46
CONFIGURE_SHELL_NO_COMMAND_MFILL	47
CONFIGURE_SHELL_NO_COMMAND_MKDIR	29
CONFIGURE_SHELL_NO_COMMAND_MMOVE	49
CONFIGURE_SHELL_NO_COMMAND_MOUNT	37
CONFIGURE_SHELL_NO_COMMAND_NETSTATS	76
CONFIGURE_SHELL_NO_COMMAND_OBJECT	69
CONFIGURE_SHELL_NO_COMMAND_PART	68
CONFIGURE_SHELL_NO_COMMAND_PERIODUSE	57
CONFIGURE_SHELL_NO_COMMAND_PWD	25
CONFIGURE_SHELL_NO_COMMAND_QUEUE	65
CONFIGURE_SHELL_NO_COMMAND_REGION	67
CONFIGURE_SHELL_NO_COMMAND_RM	36
CONFIGURE_SHELL_NO_COMMAND_RMDIR	31
CONFIGURE_SHELL_NO_COMMAND_ROUTE	80
CONFIGURE_SHELL_NO_COMMAND_SEMA	66
CONFIGURE_SHELL_NO_COMMAND_SLEEP	12
CONFIGURE_SHELL_NO_COMMAND_STACKUSE	56
CONFIGURE_SHELL_NO_COMMAND_TASK	64
CONFIGURE_SHELL_NO_COMMAND_TTY	14
CONFIGURE_SHELL_NO_COMMAND_UMASK	20
CONFIGURE_SHELL_NO_COMMAND_UNMOUNT	39
CONFIGURE_SHELL_NO_COMMAND_WDUMP	45
CONFIGURE_SHELL_NO_COMMAND_WHOAMI	15
CONFIGURE_SHELL_NO_COMMAND_WKSPACE	59
R	
rtms_shell_init	6
rtms_shell_rtms_main_alias	8
rtms_shell_rtms_main_blksync	40
rtms_shell_rtms_main_cat	35
rtms_shell_rtms_main_cd	42
rtms_shell_rtms_main_chdir	28
rtms_shell_rtms_main_chmod	34
rtms_shell_rtms_main_chroot	32

<code>rtems_shell_rtems_main_config</code>	61	<code>rtems_shell_rtems_main_netstats</code>	76
<code>rtems_shell_rtems_main_cp</code>	23	<code>rtems_shell_rtems_main_object</code>	69
<code>rtems_shell_rtems_main_cpuuse</code>	55	<code>rtems_shell_rtems_main_part</code>	68
<code>rtems_shell_rtems_main_date</code>	9	<code>rtems_shell_rtems_main_perioduse</code>	58
<code>rtems_shell_rtems_main_dir</code>	41	<code>rtems_shell_rtems_main_pwd</code>	25
<code>rtems_shell_rtems_main_dname</code>	71	<code>rtems_shell_rtems_main_queue</code>	65
<code>rtems_shell_rtems_main_driver</code>	70	<code>rtems_shell_rtems_main_region</code>	67
<code>rtems_shell_rtems_main_echo</code>	11	<code>rtems_shell_rtems_main_rm</code>	36
<code>rtems_shell_rtems_main_extension</code>	63	<code>rtems_shell_rtems_main_rmdir</code>	31
<code>rtems_shell_rtems_main_id</code>	13	<code>rtems_shell_rtems_main_route</code>	80
<code>rtems_shell_rtems_main_ifconfig</code>	77	<code>rtems_shell_rtems_main_sema</code>	66
<code>rtems_shell_rtems_main_itask</code>	62	<code>rtems_shell_rtems_main_sleep</code>	12
<code>rtems_shell_rtems_main_logoff</code>	16	<code>rtems_shell_rtems_main_stackuse</code>	56
<code>rtems_shell_rtems_main_ls</code>	26	<code>rtems_shell_rtems_main_task</code>	64
<code>rtems_shell_rtems_main_malloc</code>	51	<code>rtems_shell_rtems_main_tty</code>	14
<code>rtems_shell_rtems_main_mdump</code>	44	<code>rtems_shell_rtems_main_umask</code>	20
<code>rtems_shell_rtems_main_medit</code>	46	<code>rtems_shell_rtems_main_unmount</code>	39
<code>rtems_shell_rtems_main_mfill</code>	47	<code>rtems_shell_rtems_main_wdump</code>	45
<code>rtems_shell_rtems_main_mkdir</code>	29	<code>rtems_shell_rtems_main_whoami</code>	15
<code>rtems_shell_rtems_main_mmove</code>	49	<code>rtems_shell_rtems_main_wkspc</code>	59
<code>rtems_shell_rtems_main_mount</code>	38		

Concept Index

initialization 6

Command Index

A

alias 8

B

blksync 40

C

cat 35
 cd 42
 chdir 28
 chmod 33
 chroot 32
 config 61
 cp 21
 cpuuse 54

D

date 9
 dir 41
 dname 71
 driver 70

E

echo 10
 exit 17
 extension 63

I

id 13
 ifconfig 77
 itask 62

L

logoff 16
 ls 26

M

malloc 50
 mdump 44
 medit 46
 mfill 47
 mkdir 29
 mmove 49

mount 37

N

netstats 74

O

object 69

P

part 68
 perioduse 57
 pthread 72
 pwd 25

Q

queue 65

R

region 67
 rm 36
 rmdir 31
 route 79

S

sema 66
 sleep 12
 stackuse 56

T

task 64
 tty 14

U

umask 20
 unmount 39

W

wdump 45
 whoami 15
 wkspace 59

